

Dunlop



CRY BABY MINI WAH

925030211 12 REVA



JHM9 JIMI HENDRIX™ CRY BABY® MINI WAH

POWER

The Jimi Hendrix™ Cry Baby Mini Wah is powered by one 9-volt battery (accessed via the bottom of the pedal), an AC adapter such as the Dunlop ECB003, or the DC Brick™ and Iso-Brick™ power supplies.

SETUP INSTRUCTIONS

- Run a shielded instrument cable from your guitar to the JHM9's INSTRUMENT jack. Run another shielded instrument cable from the JHM9's AMPLIFIER jack into your amplifier input.
- Turn on the amplifier and begin playing.
- To turn the pedal on/off, push the toe of the pedal down until you feel a "click."

- Rock your foot back and forth on the pedal to instantaneously change the effect that the Cry Baby Wah has on the tone of your instrument.
- Located under the rocker at the heel of the pedal is an adjustable torque clutch. Turn clockwise to increase resistance or counterclockwise to decrease resistance (Wrench included). **See Diagram A.**

DIAGRAM A



SPECIFICATIONS

Impedance

Input	800 kΩ
Output	10 kΩ

Resonant Frequency

Heel Down	248Hz - 310Hz
Toe Down	1250Hz - 1600Hz

Maximum Level

Input	-8.0 dBV
Output	+10 dBV

Maximum Gain

Heel Down	+16.5 dB
Toe Down	+16.0 dB

Current Draw

900 μA

