



LIVE TO PLAY LIVE®

**Dunlop**  
JIMDUNLOP.COM

92503010544revB

**MXR**

ZW44 BERZERKER OVERDRIVE

# ZW44 BERZERKER OVERDRIVE

## DESCRIPTION


- Powerful, cutting overdrive with great definition
- Output and Gain controls for any tone at any volume
- Single Tone control makes sound shaping simple

## POWER

The MXR Berzerker Overdrive is powered by one 9-volt battery (remove bottom plate to install), a 9-volt AC adapter such as the Dunlop ECB003/ECB003E or a DC Brick™ power supply.

## CONTROLS

- 1 OUTPUT knob controls overall effect volume
- 2 TONE knob shapes overall EQ
- 3 GAIN knob controls amount of distortion
- 4 FOOTSWITCH toggles effect on/ bypass (red LED indicates on)



## DIRECTIONS

- Run a cable from your guitar to the Berzerker Overdrive's INPUT jack and run another cable from the Berzerker Overdrive's OUTPUT jack to your amplifier.
- Start with all controls at 12 o'clock.
- Turn the effect on by depressing the footswitch.
- Rotate OUTPUT control clockwise to increase overall effect volume or counterclockwise to decrease it.
- Rotate TONE knob clockwise for a brighter tone or counterclockwise for a warmer tone.
- Rotate GAIN knob clockwise to increase amount of distortion or counterclockwise to decrease it.

## SAMPLE SETTINGS

### ZAKKS SETTING

\* PRE AMP SETTING AT 10



### MORE OVERDRIVE



### YOUR SETTING



## SPECIFICATIONS

Input Impedance	1 MΩ
Output Impedance	7.5 kΩ
Nominal Input	-22 dBV
Noise Floor*	-88 dBV
Bypass	Hardwire
Current Draw	2.2 mA
Power Supply	9 volts DC

\*A-weighted



DUNLOP MANUFACTURING, INC.  
P.O. BOX 846 BENICIA, CA 94510 U.S.A.  
TEL: 1-707-745-2722 FAX: 1-707-745-2658