

Product Manual: Baby Terror

Thank you for choosing Orange.

Since its founding in 1968, Orange Amplification has been built by guitarists, for guitarists. Today, backed by a team of passionate industry-leading engineers, the company continues to push the limits of traditional amp design—delivering cutting-edge heads, cabinets, and combos for players everywhere.

Orange's commitment to quality control, construction and craftsmanship is long established, and each amplifier passes through a rigorous test procedure before shipping, resulting in complete confidence that you will be delighted with your new purchase, and that it will provide you many years of enjoyment and reliability.

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarised or grounding-type plug. A polarised plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

WARNING! TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE

Where indicated or stated on the product/unit, this device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for digital devices of its class, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or a qualified technician for help.

Note: Changes or modifications not expressly approved by Orange Music Electronic Company, Ltd. could void the user's authority to operate the equipment.

For customers in Canada: Where indicated or stated on the product/unit, this digital apparatus complies with Canadian Interference Regulations CAN ICES-3(B)/NMB-3(B).

All products are certified and tested to relevant safety standards. For further information, please contact us at support@orangeamps.com

	The exclamation point within an equilateral triangle and "WARNING" are intended to alert the user to the presence of important operating or servicing instructions. Failure to heed the instructions can result in severe injury or death. This equipment should be used under the supervision of an adult at all times.
	The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of un-insulated 'dangerous voltage' within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.
	This symbol indicates this product is classified as Waste Electrical and Electronic Equipment (WEEE) in the European Union and should not be discarded with household waste. Contact your local authority for more information and details of your nearest approved disposal facility.
	The "Caution, hot surface" symbol indicates that the marked item may be hot. Ensure the apparatus is installed with plenty of space around the unit (> 6"/12.5cm) as this apparatus may generate heat under normal use. This equipment is not intended to be used on soft support (like beddings, blankets etc.). This equipment should always be placed on a flat, stable surface.
	To reduce the risk of fire and electric shock do not expose this apparatus to rain or moisture. Do not use in damp environments, e.g. bathrooms etc.
	Do not place objects containing liquids on, or near the product. Do not operate this apparatus or connect/disconnect a power plug whilst hands are wet.
	Do not attempt to gain access to the interior of the product. No user serviceable parts inside. Refer all servicing to qualified servicing personnel.

BEFORE USING YOUR AMPLIFIER

Before using your amplifier: Always ensure the amp's volume control(s) are set to zero before switching on the power to the amplifier. To prevent hum and electrical noise, operate your amplifier and instruments as far away from other electronic devices (especially fluorescent and neon lamps) as possible, as devices such as these generate extremely high levels of electronic noise.

Speaker output connections:

1. Make sure the correct speaker is connected at all times during operation.
2. Do not connect to a speaker load which is less than 8 Ohms in total.
3. Always connect to a cabinet of an appropriate power rating/handling.
4. Never use two cabinets of different/mismatched impedance.
5. Only connect speakers using a quality dedicated speaker cable. Never use an instrument cable.
6. Never connect headphones to the speaker outputs.
7. If you are unsure, please contact your Orange dealer.

Manufacturer:

Orange Music Electronic Co. Ltd, 108 Ripon Way, Borehamwood, Hertfordshire, WD6 2JA, UK
 Website: orangeamps.com Email: support@orangeamps.com

EU Representative:

Authorised Rep Compliance Ltd, Ground Floor, 71 Lower Baggot Street, Dublin, D02 P593, Ireland
 Website: arccompliance.com

FRONT PANEL - TOP ROW

	POWER ON/OFF SWITCH: The volume LED will glow when the switch is set to ON. Set the volume control to zero before switching on the amplifier.
	FS VOLUME: Additional footswitchable volume ideal for lead boosts Adjusts the overall output volume.
	VOLUME: Adjusts the overall output volume. Experiment with the Gain control to achieve the desired balance.
	GAIN: Adjusts the gain level. A variety of tones can be achieved, from clean (low settings) to heavy distortion (higher settings) and everywhere in between. Note: With the Gain set to zero, no sound will be heard.
	TUBBY: The Tubby Switch allows more low-end frequencies into the circuit early on and is intended to add body when it is being used clean. The Tubby switch will add more low-end regardless of where the gain is set to. The Tubby Switch is active when in the up position.
	INPUT: Use a quality shielded instrument cable to connect your instrument to the Input jack socket.

FRONT PANEL - BOTTOM ROW

	PRESENCE: The Presence control filters the highest frequencies. When turned anticlockwise, these frequencies are gradually removed and are boosted when the control is turned clockwise. This upper-treble boost or cut is increasingly noticeable as volume rises and has a far more dramatic effect on the top end of your tone than the Treble knob.
	TREBLE: This controls the volume of the treble frequencies.
	MIDDLE: This controls the volume of the mid-range frequencies.
	BASS: This controls the volume of the bass frequencies.

REAR PANEL

	FX LOOP: Used to place external effects between the amplifier's preamplifier section and power amplifier section. Connect the SEND jack to the input of external effects. Connect the output of external effects to the RETURN jack.
--	---

	FOOTSWITCH: Connect a latching footswitch (e.g. Orange FS-1) to remotely select between: VOLUME - FS Volume / Volume
	DI OUT: The D.I OUT outputs a BALANCED signal. The Ground Lift switch can solve ground loop issues caused by connecting to more than one piece of grounded equipment. Lifting this ground connection can eliminate unwanted hum in this situation. (No CAB Sim)
	GROUND LIFT SWITCH: Engage this button if ground hum becomes a problem when hooked up to external equipment.
	SPEAKER OUTPUT: Connect to a speaker cabinet rated at 8 or 16 Ω (minimum 20 W power handling). Always use a dedicated speaker cable (not an instrument cable).

PRODUCT SPECIFICATION TABLE	
Features	FX Loop, Footswitchable second volume control, Balanced Out.
Output Power	20 Watts
Controls	FS Volume, Volume, Gain, Tubby Switch, Presence, Treble, Middle, Bass
Output Impedance	8-16 Ohms

DC POWER SUPPLY SPECIFICATION TABLE	
Mains Input Power	31 VA
Mains Input Voltage	100-240V
Output	15V 2A